

# All-In-One Audio & Visual Digital Media Platform

## **INITIAL SETUP**

Unpack your Harmony device and place it in an area with adequate ventilation. Connect cables in this order:

STEP 1: To connect Harmony to a screen, plug the HDMI cable into the HDMI output of the device and to the input of your monitor.

STEP 2: Plug the power adapter into the back of Harmony and plug it in to an 'always on' outlet - Harmony is energy efficient and optimised to run 24/7, so do not use an outlet that is controlled by a switch or electrical timer. Be sure to only use the power adapter provided.

STEP 3: Turn on your visual display. Please note that you may need to adjust your display to match the level you are accustomed to.

After 1-3 minutes, your visual content should start to play.

### **REBOOTING**

STEP 1: Remove the power cable and leave off for 5 mins STEP 2: Plug the power cable back into the media player STEP 3: The device should automatically start playing

### **TECHNICAL SUPPORT**


Email: support@dmx.co.za

011 780 3000 (Office Hours - 08:30 - 17:00)

071 884 3664 (After Hours, Weekends, Public Holidays)

#### Front Panel





Right Panel



